



WIND One

ERGONOMIC GAMING CHAIR
御風ONE 超跑人體工學椅

ENGLISH

- BREATHABLE MESH FABRIC
- FOAM PRESSURE-RELIEF SEAT
- ADJUSTABLE BACKREST
- HEIGHT-ADJUSTABLE ARMREST
- LOAD CAPACITY 120kg

РУССКИЙ

- СЕТКИ ДЫШАЩАЯ ЭЛАСТИЧНАЯ
- ПЕННОЕ СИДЕНЬЕ С РАЗГРУЗКОЙ ДАВЛЕНИЯ
- РЕГУЛИРУЕМАЯ СПИНКА
- РЕГУЛИРУЕМЫЕ ПО ВЫСОТЕ ПОДЛОКОТНИКИ
- ГРУЗОПОДЪЕМНОСТЬ 120кг

ESPAÑOL

- ELÁSTICA DE MALLA TRANSPIRABLE
- ASIENTO DE ESPUMA CON ALIVIO DE PRESIÓN
- RESPALDO AJUSTABLE
- REPOSABRAZOS AJUSTABLES EN ALTURA
- CAPACIDAD DE CARGA 120kg

PORTUGUÊS

- MALHA RESPIRÁVEL ELÁSTICA
- ASSENTO DE ESPUMA COM ALÍVIO DE PRESSÃO
- ENCOSTO AJUSTÁVEL
- APOIOS DE BRAÇO AJUSTÁVEIS EM ALTURA
- CAPACIDADE DE CARGA 120kg

日本語

- 伸縮 メッシュ 生地
- フォーム減圧シート
- 調節可能な背もたれ
- 高さ調節可能なアームレスト
- 耐荷重120kg

한국어

- 통기성 메쉬 패브릭
- 폼 압력 완화 시트
- 조절 가능한 등받이
- 높이 조절 가능한 팔걸이
- 적재 능력 120kg

繁體中文

- 高彈力透氣網布
- 成型棉紓壓椅座
- 可調式椅背
- 高低可調扶手
- 承重120公斤

简体中文

- 高彈力透氣網布
- 定型綿減壓椅座
- 可調式椅背
- 高低可調扶手
- 承重120公斤

WARRANTY CONDITIONS

Product : WIND ONE SERIES ERGONOMIC GAMING CHAIR

The product warranty period is calculated from date of purchase. MarsRhino warrants that the product will not have any material or quality defects during the warranty period. If a product requires warranty service, proof of purchase (purchase receipt or invoice) must be produced during the warranty period.

MarsRhino's warranty is limited to providing new parts to repair the product. When the product cannot be repaired, it may be exchanged for a product with the identical model number. If the product is no longer produced or unavailable, a product with similar functions or specifications may be substituted. The warranty period of the exchanged product is the original product's remaining warranty period, or 90 days, whichever is longer.

This warranty is subject to local laws and regulations. You also enjoy locally-granted warranty rights.

WARRANTY NOT APPLICABLE

- Where there has been human error, abnormal use, or force majeure (e.g., storm, flood, fire, earthquake, war, lightning, electrical surges, etc.).
- When the product number is reused, modified, damaged, illegible, etc.
- Where there has been disassembly, modification, or replacement of original parts, either oneself or by a merchant not authorized by the original manufacturer.
- Where the product has been used in a manner not in accordance with the instructions.
- To accessories, instructions, and packaging other than the product itself.

WARNING

- Please wear protective gloves when assembling the chair. It is your own responsibility to use appropriate protection to prevent any physical damage.
- Pay attention to your hand's position and keep it away from spaces in which it could get caught or be injured.
- Keep in mind that this chair is designed only for sitting and reclining, and that it should be used only for those uses.
- Do not sit on the edge of the chair or the arm rests.
- When the chair is moving, please do not touch any of the chair's adjustment controls to prevent affecting its stability and causing a potentially dangerous fall.
- When reclining the chair, please keep both feet on the ground, as well as abstain from any violent, rough or strong movement which could cause the chair to tip over.
- Do not place the chair in a location in which it is likely to be subjected to prolonged sunlight exposure. The product's colors might fade when exposed to sunlight.
- Do not use abrasive products or scrub energetically when cleaning. Please stick to gentle products suitable for delicate materials.
- If any part of the product is damaged, missing or loose, please contact the local distributor and do not use the product.

CUSTOMER SERVICE

Please contact the retailer where you purchased the product first, If you still cannot solve the problem, please contact us at the following email address.
Email: rma@marsrhino.com

www.marsrhino.com


椅座高度調整 HEIGHT LIFT



椅背高度調整 BACKREST HEIGHT LIFT



高低可調扶手 HEIGHT-ADJUSTABLE ARMREST



如何清潔人體工學椅


請以毛巾或棉布沾清水進行擦拭，並避免過多水分滲入椅子造成發霉生銹。

HOW TO CLEAN THE ERGONOMIC CHAIR?

Please wipe with a towel or cotton cloth dampened with clean water, and avoid excessive water infiltration into the chair and cause mold or rust.

鎖定傾仰

HOW TO LOCK THE POSITION OF THE BACKREST



解除傾仰


HOW TO UNLOCK THE POSITION OF THE BACKREST



椅背防回彈 安全設計 SAFETY DESIGN

解鎖後，需再往後靠輕壓椅背，聽到“嗒”聲即可解除鎖定，回正椅背。
Lean back into seat to unlock backrest.

組裝配件 ASSEMBLY DRAWING



零件包 ACCESSORY KIT

