



ETERNAL One

ERGONOMIC GAMING CHAIR
永恆ONE 超跑人體工學椅



ENGLISH

- RACING STYLE
- NAPPA LEATHER
- SEAT TILT & LOCK
- ALUMINUM PAINT LEGS
- CLASS-4 GAS LIFT CYLINDER
- LOAD CAPACITY : 100kg

РУССКИЙ

- ГОНОЧНЫЙ СТИЛЬ
- КОЖА НАППА
- НАКЛОН И БЛОКИРОВКА СИДЕНЬЯ
- ГАЗЛИФТНЫЙ ЦИЛИНДР КЛАССА 4.
- АЛЮМИНИЕВЫЕ НОЖКИ
- ГРУЗОПОДЪЕМНОСТЬ 100 КГ

ESPAÑOL

- ESTILO D E CARRERAS
- PIEL NAPA
- INCLINACIÓN Y BLOQUEO DEL ASIENTO
- PATAS DE ALUMINIO
- CILINDRO DE ELEVACIÓN DE GAS CLASE 4
- CAPACIDAD DE CARGA 100kg

PORTUGUÊS

- ESTILO DE CORRIDA
- COURO NAPPA
- INCLINAÇÃO E BLOQUEIO DO ASSENTO
- CILINDRO DE ELEVÇÃO DE GÁS CLASSE 4
- PERNAS DE ALUMÍNIO
- CAPACIDADE DE CARGA 100kg

日本語

- レーシングスタイル
- ナッパレザー
- シートチルト&ロック
- クラス4ガスリフトシリンダー
- アルミ脚
- 耐荷重100kg

한국어

- 레이싱 스타일
- 나파 가죽
- 시트 틸트 & 잠금
- 4등급 가스 리프트 실린더
- 알루미늄 다리
- 적재 능력 100kg

繁體中文

- 超跑風格設計
- Nappa納帕皮革
- 傾仰鎖定功能
- 鋁合金烤漆椅腳
- 4級氣壓棒(德國TUV認證)
- 安全承重: 100kg

简体中文

- 超跑风格设计
- Nappa纳帕皮革
- 倾仰锁定功能
- 4级气压棒(德国TUV认证)
- 铝合金椅脚
- 承重100公斤

WARRANTY CONDITIONS

Product : ETERNAL ONE SERIES ERGONOMIC GAMING CHAIR

The product warranty period is calculated from date of purchase. MarsRhino warrants that the product will not have any material or quality defects during the warranty period. If a product requires warranty service, proof of purchase (purchase receipt or invoice) must be produced during the warranty period.

MarsRhino's warranty is limited to providing new parts to repair the product. When the product cannot be repaired, it may be exchanged for a product with the identical model number. If the product is no longer produced or unavailable, a product with similar functions or specifications may be substituted. The warranty period of the exchanged product is the original product's remaining warranty period, or 90 days, whichever is longer.

This warranty is subject to local laws and regulations. You also enjoy locally-granted warranty rights.

WARRANTY NOT APPLICABLE

- Where there has been human error, abnormal use, or force majeure (e.g., storm, flood, fire, earthquake, war, lightning, electrical surges, etc.).
- When the product number is reused, modified, damaged, illegible, etc.
- Where there has been disassembly, modification, or replacement of original parts, either oneself or by a merchant not authorized by the original manufacturer.
- Where the product has been used in a manner not in accordance with the instructions.
- To accessories, instructions, and packaging other than the product itself.

WARNING


- Please wear protective gloves when assembling the chair. It is your own responsibility to use appropriate protection to prevent any physical damage.
- Pay attention to your hand's position and keep it away from spaces in which it could get caught or be injured.
- Keep in mind that this chair is designed only for sitting and reclining, and that it should be used only for those uses.
- Do not sit on the edge of the chair or the arm rests.
- When the chair is moving, please do not touch any of the chair's adjustment controls to prevent affecting its stability and causing a potentially dangerous fall.
- When reclining the chair, please keep both feet on the ground, as well as abstain from any violent, rough or strong movement which could cause the chair to tip over.
- Do not place the chair in a location in which it is likely to be subjected to prolonged sunlight exposure. The product's colors might fade when exposed to sunlight.
- Do not use abrasive products or scrub energetically when cleaning. Please stick to gentle products suitable for delicate materials.
- If any part of the product is damaged, missing or loose, please contact the local distributor and do not use the product.

CUSTOMER SERVICE


Please contact the retailer where you purchased the product first, If you still cannot solve the problem, please contact us at the following email address. Email: rma@marsrhino.com

www.marsrhino.com


椅座高度調整 HEIGHT LIFT





椅背傾仰調整 SEAT TILT & LOCK PADDLE



鎖定傾仰 HOW TO LOCK THE POSITION OF THE BACKREST




解除傾仰 HOW TO UNLOCK THE POSITION OF THE BACKREST



HOW TO CLEAN THE ERGONOMIC CHAIR?
Please wipe with a towel or cotton cloth dampened with clean water, and avoid excessive water infiltration into the chair and cause mold or rust.

組裝配件 ASSEMBLY DRAWING



零件包 ACCESSORY KIT

